



Design, performance, and limitations of the Field Reversal APS

Nulltimate
Final Report
7th April 2009
ESA-ESTEC

R. Launhardt
(MPIA Heidelberg)

Y. Rabbia



FR-APS



Outline:

1. Working principle
2. Involved Institutions and People
3. History
4. Specifications and Performance of Breadboard
5. Advantages and Intrinsic Limitations of the FR-APS for Nulling Interferometry
6. Conclusions




FR APS



Principle

- Geometrical pupil flip = reversal of electric field = π phase jump
- A pair of mirror-symmetric right-angle periscopes (two reflections on flat mirrors in each arm) yields a relative 180° rotation of both the input fields and the apertures
- Same principle as focus crossing, but with two successive 1-D flips instead of one 2-D flip





FR APS



Institutions and people involved

- ESA
- IAS
- MPIA, Heidelberg (*R. Launhardt, O. Chesneau, D. Butler*)
=> Lead in all phases, characterization measurements
- Kayser-Threde GmbH, Munich (*E. Schmidt, M. Erdmann, T. Stuffer*)
=> Modeling, assessment, design
- Fraunhofer Institute for Applied Optics, Jena (*E. Beckert, G. Harnisch*)
=> Manufacturing of breadboard device



Fraunhofer Institut
Angewandte Optik
und Feinmechanik



FR APS



History

- 2001: Method developed in parallel at JPL and EADS-Astrium, published first by Serabyn and Colavita (Appl. Optics, 40, 1668)
- 2002: Phase-Shifter Study for Darwin Nulling Interferometer (Nulltimate Project)
- 2003, Phase 1: Assessment and modelling (**KT & MPIA**)
- 2005, Phase 2a: Manufacturing of Breadboard device (**MPIA & IOF**)
- 2006, Phase 2b: Characterization measurements (**MPIA**)
- 2006: KIN reaches in Lab nb 10000:1, wb 5000:1, and on sky repeatable 100:1 nulls
- 2007: TPF nulling breadboard at JPL reaches 10^{-6} rejection monochromatic and $2 \cdot 10^{-5}$ with 20% bandwidth. JPL testbed terminated.
- 2007: FR-APS Hardware and breadboarding report delivered to IAS



FR APS

Breadboard Device

WP 3120 Final Report by MPIA Heidelberg, November 2006


R. Launhardt, D. Butler, O. Chesneau

Manufactured by Fraunhofer IOF Jena, Dept. for micro-positioning




Fraunhofer Institut Angewandte Optik und Feinmechanik


- Zerodur prisms and baseplate
- Flat polished surfaces
- Molecular adhesion bonding with *highest possible angular accuracy*
- Reflective surfaces: 240 nm sputtered Au, unprotected



KT Model



IOF device



MPIA measurement setup



FR APS



Specifications and Characterization of FR APS

Item	Spec	Measurement		Comment
		FR-APS1	FR-APS2	
WFE RMS [$l=0.63\text{mm}$, $f_{\text{beam}}=15\text{mm}$]	$\leq 30\text{ nm}$	39 nm	45 nm	(OK) (Slightly out of spec, but acceptable with spatial filtering)
Introduced beam tilt	$< 20\text{arcsec}$	$< 15\text{arcsec}$	$< 15\text{arcsec}$	OK* (next slide) (all mirrors within 8 arcsec to nominal orientation)
Polarization rotation	$< 0.5\text{deg}$	Compatible with model	Compatible with model	(OK) Could not be measured with required accuracy. By assessment well within spec
Flatness of polished back-surfaces	$< 60\text{nm}$	$< 9\text{ nm}$	$< 9\text{ nm}$	OK (only needed for alignment)



FR APS



Beam tilt introduced by the FR APS units

- The beam tilt (out – in) depends on the alignment of the APS units with the incoming beam axis
- Specified and polished reference surfaces at prism sides are used for alignment
- For „perfect“ alignment of the as-built APS units, the introduced beam tilt is < 10 arcsec
- Beam tilt is < 15 arcsec as long as the reference surface is aligned to better than ± 5 arcsec with the incoming beam



FR APS



Expected Performance as Phase Shifter

The as-built device is expected to provide a stable on-axis 180° (π) phase shift and better 10^{-6} null between two afocal beams of 15mm diameter *if*:

- Vibrations and mechanical drifts are under control
- Incoming beams are afocal (divergence $< \pm 0.7^\circ$) and fully symmetric in terms of intensity and polarization
- APS reference surfaces are aligned to incoming beam to better $\pm 5''$
- Incoming beam coherence $> 1 \dots 2 \times 10^{-6}$ (0.999998)
over the full pupil size
- The beam combiner is fully symmetric and preserves the polarization symmetry



FR APS



Advantages of the FR-APS design

- Simple principle and simple realization
- Feasible with current technology for reasonable price
- Intrinsically achromatic, i.e., suited for broad-band MIR
- Full symmetry between the two arms
- No powered optics
- No control loops or fine tuning
- Phase shift and beam combination are separated
- Potentially space-qualified



FR APS



Limitations and drawbacks for stellar nulling and exoplanet observations

- Fixed π phase shift, not adjustable, limits application range and requires other phase shifter if adjustments are necessary
- Very strict requirements on coherence, polarization symmetry, and beam combiner may push the price of the periphery
- Testbench issue: vertical beam displacement
- Consequence of pupil / FoV flip: sky regions covered by the refracted beams of the two telescopes overlap only partially. The result is a **reduced interferometric FoV** and **fringe contrast loss**, i.e., significantly **reduced transmission** and decreased SNR in white fringe where the planet is (see Hénault 2006)
- Transmission losses may still be less severe than for transmissive APS



FR APS



Conclusions

- The breadboard device was **built** with the **highest accuracy** (surfaces & alignment of bonded surfaces) that is currently possible
- The breadboard device **complies with all specs** that should enable it to **provide a broad-band Null $<10^{-6}$** , **if** beam combiner and periphery comply with all their specs
- The predicted performance has not been tested on a cryogenic nulling test bench
- Since JPL also failed to reach good nulling with FR APS (reason remains unknown), the practical nulling performance remains unproven